

## HOW TO PRINT CONFIGURATION REPORT FOR THE C1110

1. Press the [Menu] button on the front of the machine to display [Report/List], press [Eject/Set] button to accept.
2. Use the [Up] and [Down] arrow buttons to display [Printer Settings].
3. Press the [Eject / Set] button to print the selected report.